

## MOSAIC PLAYER – Quick Reference

### DMX Channel Assignment

DMX Channel Assignment													
Channel	Description												
1	General Dimmer (HTP)												
2	Command (LTP) <table border="1" style="margin-left: 20px; width: 80%;"> <thead> <tr> <th style="background-color: #D3D3D3;">Ch Range</th> <th style="background-color: #D3D3D3;">Function</th> </tr> </thead> <tbody> <tr> <td>221-255</td> <td>PLAY INDEXED MOVIE</td> </tr> <tr> <td>201-220</td> <td>PLAY CURRENT</td> </tr> <tr> <td>141-200</td> <td>PAUSE OFF (Play from current position)</td> </tr> <tr> <td>101-140</td> <td>PAUSE ON</td> </tr> <tr> <td>0-100</td> <td>STOP</td> </tr> </tbody> </table> <p>N.B. In order to be received correctly, command must be transmitted for at least one ArtNet frame (approx. 40ms)</p>	Ch Range	Function	221-255	PLAY INDEXED MOVIE	201-220	PLAY CURRENT	141-200	PAUSE OFF (Play from current position)	101-140	PAUSE ON	0-100	STOP
Ch Range	Function												
221-255	PLAY INDEXED MOVIE												
201-220	PLAY CURRENT												
141-200	PAUSE OFF (Play from current position)												
101-140	PAUSE ON												
0-100	STOP												
3	Movie Index (LTP)												
4	Play Next Movie (event generated with transition from 0 to FULL)												
5	Play Previous Movie (event generated with transition from 0 to FULL)												

### Keyboard Shortcut

Keyboard Shortcut	
KEY	Description
CMD+Y	Play Selected Movie
CMD+N	Play Next Movie
CMD+V	Play Previous Movie
CMD+P	Pause
CMD+Z	Select Next Movie
CMD+X	Select Previous Movie
CMD+S	Stop
CMD+G	GoTo
CMD+F	Full Screen
CMD+C	Hide/Show Cursor and Control Window